## image-processing-coding

## November 3, 2024

```
[10]: import numpy as np
      from scipy.fftpack import dct, idct
      from PIL import Image
      import heapq
      from collections import defaultdict
      import math
      import struct
      def dct_compression(image, quality_factor=30):
          """Transform Coding using DCT with improved compression"""
          height, width = image.shape
          block size = 8
          compressed_data = []
          for i in range(0, height, block_size):
              for j in range(0, width, block_size):
                  block = image[i:i+block_size, j:j+block_size]
                  if block.shape[0] != block_size or block.shape[1] != block_size:
                      padded = np.zeros((block_size, block_size))
                      padded[:block.shape[0], :block.shape[1]] = block
                      block = padded
                  dct_block = dct(dct(block.T, norm='ortho').T, norm='ortho')
                  q_matrix = np.ones((block_size, block_size)) * quality_factor
                  q_matrix[0:4, 0:4] = quality_factor // 2
                  quantized = np.round(dct_block / q_matrix)
                  compressed_data.append(quantized)
          reconstructed = np.zeros_like(image)
          block_idx = 0
          for i in range(0, height, block_size):
              for j in range(0, width, block_size):
                  dct_block = compressed_data[block_idx] * q_matrix
                  block = idct(idct(dct_block.T, norm='ortho').T, norm='ortho')
                  h = min(block_size, height-i)
```

```
w = min(block_size, width-j)
            reconstructed[i:i+h, j:j+w] = block[:h, :w]
            block_idx += 1
    return np.uint8(np.clip(reconstructed, 0, 255))
def huffman_encoding(image):
    """Huffman Encoding with chunk processing"""
    def chunks(data, size=1024):
        for i in range(0, len(data), size):
            yield data[i:i+size]
    frequencies = defaultdict(int)
    for pixel in image.flatten():
        frequencies[pixel] += 1
    heap = [[freq, [pixel, ""]] for pixel, freq in frequencies.items()]
    heapq.heapify(heap)
    while len(heap) > 1:
        lo = heapq.heappop(heap)
        hi = heapq.heappop(heap)
        for pair in lo[1:]:
            pair[1] = '0' + pair[1]
        for pair in hi[1:]:
            pair[1] = '1' + pair[1]
        heapq.heappush(heap, [lo[0] + hi[0]] + lo[1:] + hi[1:])
    huffman_dict = dict(heap[0][1:])
    # Process in chunks
    encoded_bytes = bytearray()
    current_byte = 0
    bit_count = 0
    for chunk in chunks(image.flatten()):
        for pixel in chunk:
            code = huffman_dict[pixel]
            for bit in code:
                current_byte = (current_byte << 1) | (1 if bit == '1' else 0)</pre>
                bit count += 1
                if bit_count == 8:
                    encoded_bytes.append(current_byte)
                    current_byte = 0
                    bit_count = 0
    # Handle remaining bits
```

```
if bit_count > 0:
        current_byte = current_byte << (8 - bit_count)</pre>
        encoded_bytes.append(current_byte)
    return encoded_bytes, (huffman_dict, bit_count, image.shape)
def lzw_encoding(image):
    """LZW Encoding with chunk processing"""
    chunk size = 1024
    dictionary = {bytes([i]): i for i in range(256)}
    dictionary_size = 256
    compressed = bytearray()
    def encode_chunk(chunk):
        nonlocal dictionary_size
        current = bytes([chunk[0]])
        result = bytearray()
        for byte in chunk[1:]:
            byte = bytes([byte])
            temp = current + byte
            if temp in dictionary:
                current = temp
            else:
                result.extend(dictionary[current].to_bytes(2, byteorder='big'))
                if dictionary size < 65536:
                    dictionary[temp] = dictionary_size
                    dictionary_size += 1
                current = byte
        if current:
            result.extend(dictionary[current].to_bytes(2, byteorder='big'))
        return result
    # Process image in chunks
    data = image.tobytes()
    for i in range(0, len(data), chunk_size):
        chunk = data[i:i+chunk size]
        compressed.extend(encode_chunk(chunk))
    return compressed, image.shape
def rle_encoding(image):
    """RLE with chunk processing"""
    chunk_size = 1024
    encoded = bytearray()
```

```
def encode_chunk(chunk):
        result = bytearray()
        count = 1
        current = chunk[0]
        for pixel in chunk[1:]:
            if pixel == current and count < 255:</pre>
                count += 1
            else:
                result.append(count)
                result.append(current)
                count = 1
                current = pixel
        result.append(count)
        result.append(current)
        return result
    # Process image in chunks
    flat_image = image.flatten()
    for i in range(0, len(flat_image), chunk_size):
        chunk = flat_image[i:i+chunk_size]
        encoded.extend(encode_chunk(chunk))
    return encoded, image.shape
def arithmetic_encoding(image):
    """Arithmetic Encoding with reduced precision"""
    PRECISION = 16 # Reduced precision to avoid overflow
    ONE = 2 ** PRECISION
    HALF = ONE >> 1
    QUARTER = HALF >> 1
    frequencies = defaultdict(int)
    total = 0
    for symbol in image.flatten():
        frequencies[symbol] += 1
        total += 1
    cumul = \{\}
    acc = 0
    for symbol in sorted(frequencies):
        cumul[symbol] = (acc, acc + frequencies[symbol])
        acc += frequencies[symbol]
    low, high = 0, ONE
```

```
encoded = bytearray()
    bits_to_follow = 0 # Initialize bits_to_follow here
    def output_bit(bit):
        nonlocal encoded, bits_to_follow # Add\ bits\_to\_follow\ to\ nonlocal
 \hookrightarrow declaration
        encoded.append(bit)
        while bits_to_follow > 0:
            encoded.append(1 - bit)
            bits_to_follow -= 1
    # Process each symbol
    for symbol in image.flatten():
        range_size = high - low
        high = low + (range_size * cumul[symbol][1]) // total
        low = low + (range_size * cumul[symbol][0]) // total
        while True:
            if high < HALF:</pre>
                output_bit(0)
            elif low >= HALF:
                output_bit(1)
                low -= HALF
                high -= HALF
            elif low >= QUARTER and high < 3*QUARTER:</pre>
                bits_to_follow += 1
                low -= QUARTER
                high -= QUARTER
            else:
                break
            low *= 2
            high *= 2
            if low >= ONE:
                low -= ONE
            if high >= ONE:
                high -= ONE
    # Output final bits
    bits_to_follow += 1
    if low < QUARTER:</pre>
        output_bit(0)
    else:
        output_bit(1)
    return encoded, (frequencies, total, image.shape)
def calculate_metrics(original, compressed_size):
```

```
"""Calculate Compression Ratio"""
   original_size = original.nbytes
   return original_size / compressed_size
def main():
    # Load image
    image = np.array(Image.open('image.png').convert('L'))
   # Test compressions
   reconstructed_dct = dct_compression(image)
    cr dct = calculate metrics(image, reconstructed dct.nbytes)
   rmse_dct = np.sqrt(np.mean((image - reconstructed_dct) ** 2))
    compressed_huff, _ = huffman_encoding(image)
    cr_huff = calculate_metrics(image, len(compressed_huff))
    compressed_lzw, _ = lzw_encoding(image)
    cr_lzw = calculate_metrics(image, len(compressed_lzw))
    compressed_rle, _ = rle_encoding(image)
    cr_rle = calculate_metrics(image, len(compressed_rle))
    compressed_arith, _ = arithmetic_encoding(image)
    cr_arith = calculate_metrics(image, len(compressed_arith))
    # Print results
   print(f"DCT Compression:")
   print(f"Compression Ratio: {cr_dct:.2f}")
   print(f"RMSE: {rmse_dct:.2f}\n")
   print(f"Huffman Compression:")
   print(f"Compression Ratio: {cr_huff:.2f}")
   print(f"RMSE: 0.00\n")
   print(f"LZW Compression:")
   print(f"Compression Ratio: {cr_lzw:.2f}")
   print(f"RMSE: 0.00\n")
   print(f"RLE Compression:")
   print(f"Compression Ratio: {cr_rle:.2f}")
   print(f"RMSE: 0.00\n")
   print(f"Arithmetic Compression:")
   print(f"Compression Ratio: {cr_arith:.2f}")
   print(f"RMSE: 0.00\n")
if __name__ == "__main__":
```

## main()

DCT Compression:

Compression Ratio: 1.00

RMSE: 2.41

Huffman Compression: Compression Ratio: 1.44

RMSE: 0.00

LZW Compression:

Compression Ratio: 2.17

RMSE: 0.00

RLE Compression:

Compression Ratio: 1.07

RMSE: 0.00

Arithmetic Compression: Compression Ratio: 0.18

RMSE: 0.00